


## Exercise 7-2

### Applying DAQ workflow

**Task:** Complete gaps in the application code to apply DAQ workflow  
Use Bookmark manager to navigate through tasks in the application

### 7-2.1 Update Initialize case of DAQ module (Fig. 1):


- Create proper **physical channels constants** and connect them to DAQ data cluster
- Set **False** to **Pump status** in DAQ data cluster and in **Write Pump** API



**Fig. 1. Initialize case of DAQ module**

### 7-2.2 Update DAQ Read case of DAQ module (Fig. 2):

- Use **Unbundle by name** nodes to connect proper virtual channels to **Read DI** and **Read AI** APIs
- Connect output **data** terminal of **Read DI** APIs to proper cluster elements of DAQ data
- Add **DAQ Read.vi** to continuously repeat DAQ Read loop



**Fig. 2. DAQ Read case of DAQ module**

### 7-2.3 Update AI scale.vi (Fig. 3):

Add scaling factor (**double constant**) of AI signal to match potentiometer MAX/MIN and Production Line position on Model User Interface (0..20 units)

**NOTE:** use 4,5 value for the scaling factor as the initial value, but if during testing the potentiometer does not cover all positions, update this value




Fig. 3. AI scale.vi code diagram

### 7-2.4 Update DI Read Body.vi API (Fig. 4):

Select proper polymorphic versions of **Create Virtual Channel.vi** and **DAQmx Read.vi** and connect the Vis with wires




Fig. 4. DI Read Body.vi code diagram